Ultra-Wideband Surface Mount Omni Antenna

617-7125 MHz, 2x Port



Ventev's low-profile surface mount omnidirectional antenna is ultrawideband covering frequency range from 617 to 7125 MHz. The antenna supports 5G NR and Wi-Fi 6E devices makes it ideal for deployments in Industrial IoT, vehicle rooftop, and fixed network applications. It features a compact form-factor, and a rugged design makes it suitable for any indoor and outdoor deployments including harsh environments. The antenna offers quick and simple single-hole mounting and comes with an extended lead eliminating the need for running jumpers.



MFG Part

VM-UE2OP-SM

Electrical Specifications

Frequency Bands, MHz	617-698	698-960	1710-2700	3300-7125
Polarization	2* Vertical			
Gain, dBi¹	3	3	4	6
Horizontal Beam Width	Omni (360°)			
Vertical Beam Width	60°	60°	30°	25°
VSWR	≤ 2.5	≤ 2.5	≤ 2.0	≤ 2.0
Max Input Power per Port	20			
Impedance, Ohm	50			

Mechanical Specifications

Dimensions (D x L)	Ø56 (Ø2.2) x 89 mm. (3.5 in.)
Input Connector	2x SMA Male
Pigtail	10 ft. with SMA Male connector, RG174
Radome	Black
Mounting	Surface mount (through 7/8 in. mounting hole, up to 1/2 in. of panel thickness)
Operating Temperature	-40 °C to +60 °C (-40 °F to +140 °F)
Relative Humidity	Up to 100%
Weight	1.2 lbs.

^{1.} Measured on Ø19 in. ground plane

Every Ventev antenna is RoHS compliant and covered by company's 2-year warranty program.

Features & Benefits

Connector

SMA Male

 Ultra-Wideband (617-7125 MHz) omnidirectional antenna with extended lead

SKU

601165

- Supports 5G FR1 and Wi-Fi 6E, makes it ideal for deployments in industrial IoT, vehicle rooftop and fixed network applications
- Rugged design suitable for any indoor and outdoor deployments
- Surface mounted

Ultra-Wideband Surface Mount Omni Antenna

617-7125 MHz, 2x Port



Mounting Instructions

Note: These instructions assume the antenna is being mounted to a flat metal surface.

- 1. Drill a 7/8 in. hole in the mounting surface.
- 2. Remove and retain the mounting nut.
- 3. Lower the connectors and cables through the hole.
- 4. Set the antenna flat on the mounting surface.
- 5. Install and tighten the mounting nut on the underside of the mounting surface.

Optional: Place a small bead of silicone sealant around the edge of the antenna where it sits atop the mounting surface.

Accessories Sold Separately



SKU 274461 Universal Wall or Pole/ Mast Mount Bracket



SKU 600876 Magnetic Mount Heavy Duty, 2-Leg



SKU 600881 Magnetic Mount Heavy Duty, 3-Leg